

THIRSTMAX™

Original Caddy

The Original ThirstMax caddy is designed to fit the commonly available 2 1/2 gallon water container sold in most grocery stores. If you have not punctured the top of the bottle the easiest method to install the caddy on the bottle is to turn the bottle upside down, slip the caddy over it, and align the spout into the opening. Turn the assembly right side up, and slip the retainer strap through the handle to secure the caddy to the bottle.

If the bottle has been punctured, spread the caddy open with the attaching hooks outside the opening. Lift the bottle onto the caddy pull the hooks up along the sides of the bottle. Insert the retainer strap through the handle to secure the caddy to the bottle.

Hang the assembly on fencing or the utility strap near the area of best use.

Universal Caddy

The Universal ThirstMax caddy is designed to be adjustable to your desired container. First, place the container on a flat surface, adjust the straps on the unit to approximately the size of the container, Fig. 1, and then attach the top strap, Fig. 2, making sure the hook straps are not confined behind the adjustable straps. Second, fit the bottom of the caddy to the container, Fig. 3, and attach the bottom strap, Fig. 4. Tighten the adjustable straps to the container and you are ready for use.



Fig. 1



Fig. 2



Fig. 3



Fig. 4

Cup Dispenser

The ThirstMax cup dispenser (sold separately) is for use on the ThirstMax caddy, and is designed to be adjustable for various cup sizes. The dispenser will work with the smallest and the largest cups available in most stores, however, the adjustment is a bit more critical for proper dispensing. The best cups to use are the 5 oz. to 9 oz. sizes found in nearly all grocery stores.

Here is how to set the dispenser up for use:

1. Lay the dispenser on a flat surface. You will notice a plastic strip sewn into one of the seams. This is the bottom end. There are a series of five (5) tabs along the length of the strip, bend these to a right angle (90 degrees) and orient the dispenser with the plastic strip up, as shown in Fig. 5.



Fig. 5



Fig. 6

2. Lay a column of the desired cups onto the dispenser, as shown in Fig. 6, at approximately the second tab nearest you with the lip of the first cup nearly engaging the tabs.

3. Roll the near side of the dispenser around the cups away from you where you lightly surround the cups as you roll the dispenser. It is best to have the lip of the first cup close to the tab so you will have good spacing for proper dispensing. Continue rolling until you engage the Velcro strips on the opposite end of the dispenser. There are three Velcro strips top to bottom. It may take a couple of attempts to get the dispenser just right, but you will not have to adjust again unless you change cup size, or, otherwise, open the dispenser.

4. Attach the dispenser retainer strap at the top so you don't accidentally spill the cups by turning the dispenser upside down, Fig. 7.
5. Affix the dispenser on the side of the ThirstMax caddy for use. Fig. 8.
6. To refill with fresh cups simply open the retainer strap at the top and drop in the cups.



Fig. 7



Fig. 8

Utility Strap

The utility strap, Fig. 9, is intended to wrap around a post, pole, tree, or any substrate suitable so you may attach your ThirstMax caddy to it.

Simply open the snap buckle by depressing its sides and wrap the strap around the substrate in the desired location, re-insert the tongue into the buckle. Tighten the strap around the substrate by pulling the free end of the strap securely on the substrate. Adjust the two D-rings approximately 4 inches apart and attach your ThirstMax caddy to the rings.

That's all there is to it. Enjoy.



Fig.9

Thank you for your purchase. If you have any questions or comments, please feel free to email us at info@thirstmax.com.